

In Pilsen and Online

Optimization of cell efficiency

for aqueous organic electrolyte

Vaclav Cmolik
New Technologies - Research Centre
University of West Bohemia
3rd March 2022






Engineering of electrochemical processes

- Battery and cell testing facilities
 - 10 channels
- Computed microtomography
 - in situ measurement available
- Scale up of new battery concepts
 - Zn-air
- Development of VRFB stack
 - know how licensed to Pinflow








- Studied system
 - $0.9M (SPr)_2V 0.9M Fe(CN)_6$
 - Supporting electrolyte − NH₄Cl
- Lab cell
 - Pinflow design
- Atmosphere
 - Inert gas − N₂
- Pump
 - Watson Marlow Peristaltic




- Studied system
 - $0.9M (SPr)_2V 0.9M Fe(CN)_6$
 - Supporting electrolyte NH₄Cl
- Lab cell
 - Pinflow design
- Atmosphere
 - Inert gas N₂
- Pump
 - Watson Marlow Peristaltic



Pinflow lab cell

- Scaling cell
 - $2x2 \text{ cm}^2 \rightarrow 4x5 \text{ cm}^2 \rightarrow \text{industry scale}$
- End plate →
 - cupper current collector →
 - carbon polymer composite →
 - seal \rightarrow flow frame \rightarrow felt \rightarrow
 - seal \rightarrow membrane ...




Studied system

- $0.9M (SPr)_2V 0.9M Fe(CN)_6$
- Supporting electrolyte NH₄Cl
- Membrane Fumasep FS950
- Felt SGL GFD 4.6EA

CONFIDENTIAL

• Carbon-polymer composite – PPG86




Studied system

- $0.9M (SPr)_2V 0.9M Fe(CN)_6$
- Supporting electrolyte NH₄Cl
- Membrane Fumasep FS950
- Felt SGL GFD 4.6EA
- Carbon-polymer composite PPG86
- Maximum voltage up to 1.2 V

Targets


- Finding best conditions
 - Optimal temperature
 - Flow management

- Looking for best performance
 - Highest Voltage Efficiency
 - Lowest resistance of the system
 - Predictable behavior during cycling




Targets

- Finding best conditions
 - Optimal temperature
 - Flow management
- Looking for best performance
 - Highest Voltage Efficiency
 - Lowest resistance of the system
 - Predictable behavior during cycling




Targets

- Finding best conditions
 - Optimal temperature
 - Flow management
- Looking for best performance
 - Highest Voltage Efficiency
 - Lowest resistance of the system
 - Predictable behavior during cycling



Temperature – cell 2x2 cm²


- Amount of supporting electrolyte
 - 2 M NH₄Cl in (SPr)₂V, 1M NH₄Cl in Fe(CN)₆
- Flow, Voltage
 - 20 ml/min; 0.6 1.15 V
- Tested temperature
 - 20, 30 and 40 °C
- Result
 - 20 and 40 °C \rightarrow cell 4x5 cm²




Best performance – cell 2x2 cm²

- Amount of supporting electrolyte
 - 2 M or 3M NH₄Cl in (SPr)₂V, 1M or 0M NH₄Cl in Fe(CN)₆
- Flow, Voltage
 - 20 ml/min; 0.6 1.15 V
- Tested temperature

- 20 and 40 °C
- Result
 - 40 °C
 - More than 20 % initial capacity from theoretical maximum
 - + 10 % Voltage efficiency
 - Ideal concentration of NH₄Cl which one is the best ??







Flow management – cell 2x2 cm² – SoC 50 %

- Amount of supporting electrolyte
 - 2M1M == 2 M NH₄Cl in (SPr)₂V, 1M NH₄Cl in Fe(CN)₆
- Flow range
 - From 10 to 80 ml/min
- Tested temperature
 - 20, 30 and 40 °C

- Result
 - 40 ml/min \rightarrow cell 4x5 cm²




Impedance – cell 4x5 cm² – State of charge 50 %



Note: $2M1M == 2 M NH_4Cl in (SPr)_2V$, $1M NH_4Cl in Fe(CN)_6$


 \bigcirc

Cycling performance – cell 4x5 cm²; 40 ml/min; 50 cycles




Note: $2M1M == 2 M NH_4Cl in (SPr)_2V$, $1M NH_4Cl in Fe(CN)_6$

Behavior during cycling – cell 4x5 cm²; 40 ml/min; 50 cycles



Note: $2M1M == 2 M NH_4Cl in (SPr)_2V$, $1M NH_4Cl in Fe(CN)_6$

Overflow – cell 4x5 cm²; 40 ml/min




Note: $2M1M == 2 M NH_4Cl in (SPr)_2V$, $1M NH_4Cl in Fe(CN)_6$

(0)

Conclusion

- Flow rate
 - Optimal flow was found with respect to inner resistance
- Temperature
 - 40 °C
 - lesser initial capacity loss
 - higher voltage efficiency
 - lesser resistance of system
 - lesser dependence on concentration of supporting electrolyte
- Supporting electrolyte
 - 2M0M
 - smallest difference in behavior between 20 °C and 40 °C
 - 3M0M
 - the best performance during cycling in 40 °C





Thank you!

























Disclaimer/ Acknowledgment

Copyright ©, all rights reserved. This document or any part thereof may not be made public or disclosed, copied, or otherwise reproduced or used in any form or by any means, without prior permission in writing from the HIGREEW Consortium. Neither the HIGREEW Consortium nor any of its members, their officers, employees, or agents shall be liable or responsible, in negligence or otherwise, for any loss, damage or

expense whatever sustained by any person because of the use, in any manner or form, of any knowledge, information or data contained in this document, or due to any inaccuracy, omission or error therein contained.

All Intellectual Property Rights, know-how and information provided by and/or arising from this document, such as designs, documentation, as well as preparatory material in that regard, is and shall remain the exclusive property of the HIGREEW Consortium and any of its members or its licensors, Nothing contained in this document shall give, or shall be construed as giving, any right, title, ownership, interest, license, or any other right in or to any IP, know-how and information.

This project has received funding from the European Union's Horizon 2020 research and innovation programme under grant agreement No 875613. The information and views set out in this publication does not necessarily reflect the official opinion of the European Commission. Neither the European Union institutions and bodies nor any person acting on their behalf, may be held responsible for the use which may be made of the information contained therein.